




BOSCH

Installation Manual

Gas continuous flow water heaters

HighFlow 6000

GWH16/20/26 3 CT E23/31 F6 L S2405



6720817545-00.1V



Table of contents

1 Explanation of symbols and safety instructions 3

- 1.1 Explanation of symbols 3
- 1.2 General safety instructions 3
- 1.2.1 Safety information 3

2 Product details 5

- 2.1 Declaration of Conformity 5
- 2.2 Model overview 5
- 2.3 Included items 5
- 2.4 Rating plate 5
- 2.5 Description of appliance 5
- 2.6 Optional accessories 5
- 2.7 Dimensions and minimum clearances 6
- 2.8 Appliance layout 7
- 2.9 Electrical wiring diagram 8
- 2.10 Specification 9

3 Regulations 9

4 Installation (only by authorised technicians) 9

- 4.1 Choice of installation site 10
- 4.1.1 Regulations concerning the installation site 10
- 4.2 Minimum clearances 11
- 4.3 Installing the appliance 11
- 4.4 Water connection 12
- 4.4.1 Temperature mixing device (not supplied with the appliance) 12
- 4.5 Gas connection 12
- 4.6 Altitude of installation site 12
- 4.7 Remote control connection (optional) 13
- 4.8 Electrical connection (only by authorised technicians) 13
- 4.8.1 Connecting the power cable 14
- 4.9 Commissioning of the appliance 14
- 4.10 Bluetooth instruction 14
- 4.11 Changing the setpoint limit temperature (only for 55 °C preset appliances) 15
- 4.12 Delivery temperature calibration 15

5 Regulating the gas (only for authorised technicians) 15

- 5.1 Factory settings 15
- 5.2 Service function 16

5.3 Adjusting the appliance 16

- 5.3.1 Access to test points 16
- 5.3.2 Adjusting the maximum flow (Parameter P1) 16
- 5.3.3 Adjusting the minimum flow (Parameter P2) 16
- 5.3.4 Adjusting pressure at the burner (Parameter P0) 17

5.4 Factory default settings 17

6 Maintenance (only by authorised service technician) 18

- 6.1 Periodic maintenance 18
- 6.2 Replacement of the fuse (electronic control unit) 18
- 6.3 Start-up after completion of maintenance 19

7 Troubleshooting 20

8 Environment considerations 21

9 Water quality 21

10 Warranty details 22

1 Explanation of symbols and safety instructions

1.1 Explanation of symbols

Warnings

In warnings, signal words at the beginning of a warning are used to indicate the type and seriousness of the ensuing risk if measures for minimising danger are not taken.

The following signal words are defined and can be used in this document:

DANGER:

DANGER indicates that severe or life-threatening personal injury will occur.

WARNING:

WARNING indicates that severe to life-threatening personal injury may occur.

CAUTION:

CAUTION indicates that minor to medium personal injury may occur.

NOTICE:

NOTICE indicates that material damage may occur.

Important information

The info symbol indicates important information where there is no risk to people or property.

Additional symbols

Symbol	Meaning
▶	a step in an action sequence
→	a reference to a related part in the document
•	a list entry
–	a list entry (second level)

Table 1

1.2 General safety instructions

1.2.1 Safety information

If you smell gas:

- ▶ Close the gas supply valve to the appliance.
- ▶ Isolate gas supply from gas meter or LPG cylinder.
- ▶ Do not operate any electrical appliances or switches (on/off).
- ▶ Extinguish other sources of ignition.
- ▶ Go to a different location and call the gas supplier or an authorised technician in order to check the gas supply.

If you notice dark combustion gases or sooting:

- ▶ Isolate the gas supply to the heater.
- ▶ Notify an authorised technician.

Installation, assembly, and modifications

Installation, assembly, and modifications to the heater must only be performed by an authorised technician.

Maintenance

- ▶ The water heater is required to have a service and safety inspection every two years.
- ▶ The installer is responsible for the safety and environmental compatibility of the installation, according to local regulations.
- ▶ The owner/user is responsible for keeping the area around the water heater free from debris.
- ▶ Safe access to inspect and service the water heater is the responsibility of the property owner.
- ▶ Use only genuine Bosch spare parts.

Explosive and flammable material

Do not store or use flammable material (paper, spray cans, solvents, paints, etc) near the heater.

Combustion air and surrounding air

- ▶ The combustion air and surrounding air must be free from corrosive substances.
- ▶ Do not spray aerosols or use chemicals around the heater unless heater is disconnected from the power supply.

Risk of damage due to user error

User error can result in injury and damage to property.

- ▶ Ensure that children never play with or operate this appliance.
- ▶ Ensure that only personnel who can operate this appliance correctly have access to it.
- ▶ Refer to the operating and user instructions before adjusting the water heater.

To be installed and serviced only by an authorised person

The "authorised installing person" is responsible for:

- Correct installation and commissioning of this appliance.
- Ensuring the appliance performs to the specifications stated on the rating label.
- Demonstrating the operation of the appliance to the customer before leaving.
- Handing the operating instructions to the customer.

THIS APPLIANCE IS NOT SUITABLE FOR POOL OR SPA POOL APPLICATIONS. NOT SUITABLE FOR COMMERCIAL BOOSTING OF A WARM WATER RECIRCULATION SYSTEM

Regulations

All local by-laws and regulations pertaining to installation and use of gas appliances must be observed. This appliance must be installed in accordance with the manufacturers installation instructions, AS/NZS5601, AS/NZS3500, and all Local Building & Gas fitting regulations. This appliance must not be installed indoors or in an enclosed space. This appliance is approved for outdoor installation only. Do not install this appliance with any modification or alteration. Failure to install this appliance in accordance with these installation instructions will void the warranty and may create an unsafe situation.

Installation



DANGER:

This appliance must not be installed indoors or in an enclosed space in accordance with AS/NZS5601.



DANGER:

Explosion Risk!

- ▶ Always turn off the gas valve before carrying out any work on components which carry gas.



DANGER:

Appliance malfunction!

This appliance must be installed with no obstructions to air entry openings.

- ▶ Periodic checking of openings to ensure no blockage or obstruction from plants, debris or insects must be carried out.



The installation of gas, water, and electrical supply, and the initial startup are to be performed by an authorised person.



Not suitable for pool or spa pool applications. Not suitable for commercial boosting of warm water recirculation systems.



Installation in marine environments can lead to premature corrosion. Premature corrosion due to the installation environment would not be covered by warranty.



All gas appliances require adequate air intake to ensure correct combustion. Insects and dirt ingress may affect combustion causing sooting. If you notice sooting from the flue outlet the unit would require servicing. Pest and dirt ingress is not covered by the manufacturers warranty.

Important information

- ▶ Determine the most appropriate location for the appliance. Install only on an external wall as close as possible to the most frequently used hot water outlet.
- ▶ Ensure the mounting structure is capable of supporting the weight of the appliance once installed. Secure the appliance to the wall using fixings suitable for the weight of the appliance and the wall material.
- ▶ Install gas and water isolation valves as close as possible to the appliance. Only use a gate valve or full flow ball valve (fixed mechanism type) for cold water.
- ▶ Check the cold water supply pressure to ensure it meets the required supply pressure for the appliance. (see table 5, page 9).
- ▶ If inlet water pressure exceeds 800 kPa a pressure limiting valve (500 kPa) MUST be fitted. The preferable location for the pressure limiting valve is at the water meter.
- ▶ Where the pressure limiting valve is less than 3 metres from the hot water unit, it must be fitted in conjunction with a cold water expansion valve (700 kPa), between the water heater and the pressure limiting valve.
- ▶ Failure to comply with this requirement may void the warranty.
- ▶ Refer to AS/NZS5601 for the relevant gas pipe sizing.

- After finishing the gas piping system, the pipes must be thoroughly purged and leak tested. This test must be performed with the gas isolation valve of the appliance closed.
- Ensure the gas pressure and flow through the regulator are appropriate for the consumption of the heater (see table 5, page 9). Refer to AS/NZS5601.1 for the relevant pipe size.

Note: Incorrect pipe sizing or gas supply pressure may cause the appliance to under perform. Service calls for incorrect pipe sizing and/or gas pressure, will **NOT** be covered under warranty.

Safety of electrical appliances for domestic use and similar purposes

The following requirements apply in accordance with AS/NZS60335 in order to prevent hazards from occurring when using electrical appliances:

"This appliance can be used by children of 8 years and older, as well as by people with reduced physical, sensory or mental capabilities or lacking in experience and knowledge, if they are supervised and have been given instruction in the safe use of the appliance and understand the resulting dangers. Children must not play with the appliance. Cleaning and user maintenance must not be performed by children without supervision." "If the power cable is damaged, it must be replaced by the manufacturer, its customer service department or a similarly qualified person, so that risks are avoided."

2 Product details

2.1 Declaration of Conformity

The appliance has been tested and certified to Australian Standards.

Model	GWH16/20/26 3 CT E23 F6 L S2405
--------------	---------------------------------

Table 2

2.2 Model overview

GWH	16	3	CT	E	23	F6	L
GWH	16	3	CT	E	31	F6	L
GWH	20	3	CT	E	23	F6	L
GWH	20	3	CT	E	31	F6	L
GWH	26	3	CT	E	23	F6	L
GWH	26	3	CT	E	31	F6	L

Table 3

[GWH] Gas continuous flow water heater

- [16] Capacity (l/min)
- [3] Generation
- [CT] Thermostatic
- [E] Electronic ignition
- [23] Appliance set for natural gas
- [31] Appliance set for LPG (universal LPG)
- [F6] Outdoor installation
- [L] Locked water temperature adjustment

2.3 Included items

- Gas continuous flow water heater
- Appliance documentation

2.4 Rating plate

The rating plate is located on the outside of the appliance, on the bottom. The plate specifies the performance of the appliance, approval data and the serial number.

2.5 Description of appliance

- External wall-mounted appliance
- Appliance for operating with natural gas or LPG
- Electronic ignition
- Water flow sensor
- Water valve
- By-pass valve
- Temperature sensors for monitoring the temperature of the incoming, outgoing and mixed water of the appliance.
- Safety devices:
 - Flame sensor rod
 - Thermal fuse
 - Outgoing water temperature sensor
 - Electronic control unit
 - Air temperature sensor
 - Frost-protection device
- Electrical connection: 230/240 V, 50 Hz

2.6 Optional accessories

- Main remote control
- Bathroom remote control
- Recess Box
- Flue diverters

2.7 Dimensions and minimum clearances




Fig. 1 Dimensions (in mm)

	Connections				
	Cold	Hot	Nat.	LPG	
GWH16/20/26	3/4"	3/4"	3/4"	3/4"	

Table 4

2.8 Appliance layout




Fig. 2

- [1] Flue terminal
- [2] Flame sensor rod
- [3] Burner
- [4] Air pressure test point
- [5] Water flow sensor and Water valve
- [6] Fan
- [7] Cold water temperature sensor
- [8] Hot water outlet
- [9] Cold water inlet
- [10] By-pass valve
- [11] Gas inlet
- [12] Electronic control unit
- [13] Gas valve
- [14] Gas pressure test point
- [15] Ignition electrode
- [16] Heat exchanger

2.9 Electrical wiring diagram




Fig. 3 Electrical diagram

- | | |
|--|--------------------------------------|
| [1] Flame sensor rod | [14] Air temperature sensor |
| [2] Fan | [15] Hot water temperature sensor |
| [3] Ignition electrode | [16] Cold water temperature sensor |
| [4] Power supply | [17] Water valve |
| [5] Connection for frost-protection device | [18] Outlet water temperature sensor |
| [6] Connection for remote control (optional) | |
| [7] By-pass valve | |
| [8] Modulation electrovalve (gas) | |
| [9] Segmentation electrovalve 1 (gas) | |
| [10] Segmentation electrovalve 2 (gas) | |
| [11] Safety electrovalve (gas) | |
| [12] Thermal fuse | |
| [13] Water flow sensor | |

2.10 Specification

Technical features	Units	16L	20L	26L
Performance				
Nominal gas consumption	MJ/h	122	149	199
Minimum gas consumption	MJ/h	18	18	25
Efficiency at 100% of nominal load	%	81.5	82	81
Gas supply data				
Minimum gas supply pressure (flowing)				
Natural gas (when operating)	kPa	1.13	1.13	1.13
Universal LP gas (when operating)	kPa	2.75	2.75	2.75
Water supply data				
Maximum permissible pressure (static)	kPa	1000	1000	1000
Minimum operating pressure	kPa	100	100	100
Minimum operation pressure for maximum performance	kPa	300	300	300
Minimum water flow	l/min	2	2	2
Maximum flow, corresponding to a temperature increase of 25 °C	l/min	16	20	26
Maximum inlet temperature	°C	80	80	80
Electrical circuit				
Power supply voltage	V _{AC}	230/240	230/240	230/240
Frequency	Hz	50	50	50
Maximum power consumption in standby (including frost protection)	W	165	165	228
Maximum power consumption during operation	W	57	57	70
General data				
Weight (unpacked)	kg	15	15	18
Height	mm	520	520	520
Width	mm	340	340	340
Depth	mm	170	170	170

Table 5

3 Regulations

Any local by-laws and regulations pertaining to installation and use of gas-fired appliances must be observed.

This appliance must be installed in accordance with the manufacturers installation instructions, AS/NZS5601 and all Local Building & Gas fitting regulations.

It is recommended that sanitary fixtures used for the purpose of personal hygiene have a temperature limiting device such as a tempering valve be fitted as per AS3498.

This appliance must not be installed indoors or in an enclosed space as per AS/NZS5601.

4 Installation (only by authorised technicians)



DANGER:

This appliance must not be installed indoors.



DANGER:

Explosion!

- Always shut off the gas valve before carrying out work on gas pipes.



The appliance installation, electrical connection, gas connection, and the initial start-up, are operations to be carried out by authorised technicians only.



CAUTION:

- ▶ The temperature of the incoming water of the appliance must not exceed 80 °C.
- ▶ If the incoming water temperature exceeds 80 °C, fit a 3-way or thermostatic valve adjusted to less than 80 °C (solar transfer valve).
- ▶ In the case of a thermal solar system, (see Fig. 4), ensure that the installation has an expansion vessel or valve.



Installation in marine environments can lead to premature corrosion. Premature corrosion due to the installation environment would not be covered by warranty.



Not suitable for pool or spa pool applications.



WARNING:

Scalding!

Only for 55 °C preset appliances - This appliance can deliver water exceeding 50 °C.

- ▶ Please refer to AS/NZS 3500.4 local requirements and installation instructions for additional temperature control requirements.

Thermal solar system (thermosiphon)




Fig. 4 Thermal solar system

- [1] Pre heated water line
- [2] Incoming water
- [3] Thermostatic valve
- [4] Expansion tank or valve
- [5] Pressure relief valve
- [6] Hot water line

4.1 Choice of installation site

4.1.1 Regulations concerning the installation site

- ▶ Install the appliance outdoors. The top of the unit should be positioned at less than 1800mm from the ground (the bottom should remain at more than 300mm).
- ▶ The water heater may not be installed over a heat source.
- ▶ Comply with the minimum installation clearances indicated in Fig. 5 and Table 6.
- ▶ Ensure there is an external weatherproof powerpoint in the area and it is easily accessible after the installation of the water heater.

Location of the appliance

The air intake of this appliance is located on the rear of the housing.

- ▶ Ensure this intake is free from vegetation and other obstructions.

In order to prevent corrosion, the combustion air must not contain any corrosive substances. Substances classed as corrosion-promoting include halogenated hydrocarbons containing chlorine and fluorine compounds. They may be found in solvents, paints, adhesives, aerosol propellants and household cleaners. If these conditions cannot be guaranteed, a different site must be chosen for the appliance.

Surface temperature

The maximum surface temperature of the appliance is below 85 °C. No special safety precautions are required with regard to flammable building materials.

- Ensure local building codes and regulations are followed.

4.2 Minimum clearances

- Install the appliance in accordance with the minimum installation clearances indicated in Fig. 5 and Table 6, according to AS/NZS5601.
- The appliance must not be installed over a heat source.
- Do not obstruct the openings of appliance.
- The appliance must be installed in a position that is easily accessible to allow service work. It is recommended the appliance is installed no more than 2m from the ground to the base of the appliance.
- The areas 30cms above and below the appliance must be clear of obstacles.




Fig. 5 Minimum flue clearances

Item	Min. clearance (mm)
A Below eaves, balconies and other projections	300
B From the ground, above a balcony or other surface ¹⁾	300
C From a return wall or external corner ¹⁾	300
D From a gas meter (GM)	1000
E From an electricity meter or fuse box (P) ²⁾	500
F From a drain pipe or soil pipe	75
G Horizontally from any building structure ¹⁾ or obstruction facing a terminal	500

Item	Min. clearance (mm)
H From any other flue terminal, cowl, or combustion air intake ¹⁾	300
J Horizontally from an openable window, door, nonmechanical air inlet, or any other opening into a building with the exception of sub-floor ventilation:	
Appliances up to 150 MJ/h input ¹⁾	300
Appliances over 150 MJ/h input up to 200 MJ/h input ¹⁾	300
K From a mechanical air inlet, including a spa blower	1000
N Vertically below an openable window, non-mechanical air inlet, or any other opening into a building with the exception of sub-floor ventilation:	
Appliances over 50 MJ/h input and up to 150 MJ/h input	1000
Appliances over 150 MJ/h input	1500

- 1) unless appliance is certified for closer installation
- 2) Prohibited area below electricity meter or fuse box extends to ground level

Table 6

4.3 Installing the appliance

NOTICE:

The appliance may be damaged if dirt is allowed to enter via the gas or water connections.

- Purge the pipes to eliminate possible foreign bodies.
- Remove the appliance from the packaging.
- Check that all the items indicated are included (→ section 2.3).
- Remove the covers from the gas and water connections.
- Check that the gas type available matches that shown on the sticker on the front of appliance, and on its dataplate.



CAUTION:

- Never support or balance the water heater on the water and gas connections.



Packaging materials can be recycled.

Fixing the appliance to the wall



Before fixing the appliance to the wall, ensure that the water and gas connections can be installed in this area.

Fire protection for the installation surface is not required with this appliance. The wall has to be capable of supporting the weight of the appliance.

- ▶ Mark the position of the fixing holes.




Fig. 6

- ▶ Drill holes to match the selected wall fixings (Ø 13 mm maximum).
- ▶ Fix the appliance to the wall using appropriate fixings (not supplied).



The top bracket must be used when fixing the appliance to the wall. For extra stability the appliance can also be fixed at the bottom bracket.

4.4 Water connection

- ▶ Identify the cold and hot water pipe to avoid possible cross connection.
- ▶ Install a pressure reducing valve if required. It's preferable to install this valve close to the water meter.

- ▶ Complete the cold (→fig. 2, [9]) and hot (→fig. 2, [8]) water connections.

Only for 50 °C preset appliances - The hot water line must have a minimum length of 2 meters with a ½" pipe.

4.4.1 Temperature mixing device (not supplied with the appliance)



WARNING:

This water heater can heat water to temperatures which cause scalding.

Only for 55 °C preset appliances - It is recommended that for sanitary fixtures use primarily for the purpose of personal hygiene, that a temperature control device be fitted (such as a tempering valve) as per AS3500.4.

4.5 Gas connection



DANGER:

Non-compliance with applicable legal standards may cause, material damage, personal injury, or even death.

The gas connection to the water heater must comply with AS/NZS5601.







- ▶ First ensure that the water heater corresponds to the gas type available.
- ▶ Fit a gas isolation valve on the gas supply line as close as possible to the appliance.
- ▶ After installation of the gas supply line, thorough purging and tightness test must be carried out.




Size gas supply as per AS/NZS5601. Incorrect gas pipe sizing will not be covered by the warranty.

4.6 Altitude of installation site

To ensure correct operation of the appliance at altitudes above 500m, the altitude setting must be adjusted.

- ▶ Enter the Service function (→section 5.2). Display will show "P2".
- ▶ Press  until the display shows "P4".
- ▶ Press the button . Display will show "E".
- ▶ Press  until the display shows "AS".
- ▶ Press the button . Display will show "1".
- ▶ Press the button  or  to select the altitude of the installation site according to Table 7.

- Press the  button for 3 seconds.
The value flashes to confirm the new Altitude Calibration Value.

Display	Altitude
1	< 500 m
2	500 m - 1 000 m
3	1 000 m - 1 500 m
4	1 500 m - 2 000 m
5	2 000 m - 2 500 m
6	> 2500 m

Table 7

4.7 Remote control connection (optional)

Connecting the communication cable to the remote control

- Open the remote control.
- Remove the larger connector from the communication cable.
- Connect the larger connector to the controller in the position shown in Fig. 7.
- Remove the plastic tag to allow the cable to be feed through.
- Feed the end of the cable without a connector through the opening in the back cover.
- Reconnect the cable to the larger connector.
- Refit the front and back covers back together.
- Close the remote control.




Fig. 7

- [1] Remote control front cover
- [2] Remote control back cover
- [3] Communication cable

Connecting the communication cable to the appliance

- Unscrew the electronic control unit fixing screw.
- Remove the grommet and feed the remote control communication cable through it.

- Route the cable to the inside of the appliance and connect to one of the available connectors at the base of the appliance.




Fig. 8



Up to 4 remote controls can be used for one single appliance. Appliance fitted with Bluetooth connectivity will have 3 remote control connections available.

4.8 Electrical connection (only by authorised technicians)

 **DANGER:**
Due to electric shock!

- Before carrying out work on electrical components, disconnect the power supply (230/240 V AC) by switching off the appliance and removing the power plug from the socket.

All the regulating, control and safety devices in the appliance are factory supplied already connected and ready to operate.

4.8.1 Connecting the power cable



The electrical connection must be installed in accordance with AS/NZS3000.



If the power cable is damaged, it must be replaced with a Bosch supplied spare part.

- ▶ Connect the power cable to a power socket.

4.9 Commissioning of the appliance

- ▶ Open the gas and water isolation valves and check the tightness of all the connections.

If a controller is connected:

- ▶ Turn the appliance on using the ON/OFF button. The appliance is now ready to operate.

When a hot water tap is turned on, the movement of water through the flow sensor (fig. 2, [5]) sends a signal to the electronic control unit. This signal triggers the following actions:

- The fan to start working.
- The ignition sequence and the gas valve (fig. 2, [13]) delivers gas to the burner.
- The burner ignites. Initially only one section of the burner is lit, with remain sections igniting depending on the heat required.
- The flame sensor rod (fig. 2, [2]) detects the presence of the flame.
- The temperature of the water is automatically adjusted by the fan, gas and water valves.

Safety shut-off when the safety time is exceeded

If the appliance does not maintain a flame within the safety interval stipulated, a safety shut-off is carried out. The presence of air in the gas supply line (initial start-up of the appliance or start-up after long periods of inactivity) may cause a delay or difficulty when igniting. If the ignition attempt is unsuccessful after a period of time, the safety devices block the operation of the appliance, and air will have to be purged from the circuit.

Safety shut-off due to an excessively high water temperature

The electronic control unit detects the temperature of the water through the thermistor placed at the hot water outlet. If the appliance detects an excessive temperature, a safety shut-off will occur.

Safety shut-off due to incorrect flue conditions

If the appliance detects an incorrect flue condition, a safety shut-off will occur.

Re-start after a safety shut-off

To put the appliance back into operation after a safety shut-off:

- ▶ Close all hot water taps.
- ▶ Reset the appliance by switching it off at the socket and unplugging the cord.

4.10 Bluetooth instruction

Bosch have developed Bosch Water and Bosch ProWater apps to provide User and tradesperson/installer with features that until now have not been available on a water heater. Both Apps connect to the HighFlow 6000 Bluetooth enabled appliances from a range of up to 10 meters. Note that building and construction materials used can affect Bluetooth signal, for best results be in front of the unit or in direct line of sight.

Home user **Bosch Water App** features

- Temperature control
- Running cost information
- Water consumption information
- Energy usage information

Trade professional **Bosch ProWater App** features

- Real time performance monitoring
- Real time diagnostics
- Setting adjustment for:
- Maximum set point limit
- 'At tap' temperature adjustment
- Altitude compensation
- Service procedures
- Appliance software back-up plus
- All home user features

Simple and quick connection to your smart device

The information required to pair the appliance with the app is contained on the Bluetooth data label located on the bottom of the appliance on the right hand side. See Fig 9 for location and example of the data label.

Take note of the appliance "ID" and "S/N" as these will be used to pair your device to the appliance using the app.

- ▶ Download the Bosch Water or ProWater app from the App Store or Play Store.
- ▶ Open the app and select "Search for appliances".
- ▶ Tap on your appliance "ID" listed on the app.
- ▶ Enter the appliance "S/N" as the password.
- ▶ Enjoy the control and convenience of HighFlow 6000.




Fig. 9 Bluetooth label location

4.11 Changing the setpoint limit temperature (only for 55 °C preset appliances)

The maximum temperature is preset to 55 °C. If required it can be increased to 60 °C or 70 °C.

- ▶ Enter the Service function (section 5.2). Display will show "P2".
- ▶ Press until the display shows "P4".
- ▶ Press the button . Display will show "E".
- ▶ Press until the display shows "SL".
- ▶ Press the button . Display will show "55"
- ▶ Press until the display shows "60" or "70".
- ▶ Press the button for 3 seconds. The value flashes to confirm the new setpoint limit.

4.12 Delivery temperature calibration

If the delivery temperature at the closest hot water outlet to the appliance does not match the setpoint it can be adjusted as follows:

- ▶ Enter the Service function (section 5.2). Display will show "P2".
- ▶ Press until the display shows "P4".
- ▶ Press the button . Display will show "E".
- ▶ Press until the display shows "SC".
- ▶ Press the button . Display will show "0"
- ▶ Press or to adjust the delivery temperature as required. The setpoint can be adjusted between -2.5 °C and +2.5 °C.

Display	Setpoint calibration
-5	-2.5 °C
-4	-2.0 °C
-	-
0	-0 °C
-	-
-	-
4	2.0 °C
5	2.5 °C

Table 8

- ▶ Press the button for 3 seconds. The value flashes to confirm the adjustment has been made.

Calibration example

Setpoint	Water temp. at tap	Setpoint calibration
55 °C	53 °C	+2 °C

Table 9

5 Regulating the gas (only for authorised technicians)

5.1 Factory settings

The data plate on each appliance will show the factory setting of that appliance.

Natural gas



The appliance must not be operated if the dynamic connection pressure is less than 1.13 kPa or greater than 2.75 kPa.

LPG



The appliance must not be operated if the dynamic connection pressure is less than 2.5 kPa or greater than 4.5 kPa.



! DANGER:

- ▶ The operations described below must only be carried out by an authorised technician.

5.2 Service function

Accessing the service menu

- ▶ Press and hold down at the same time **P**, **+**, **-** and for 3 seconds.




Fig. 10 Service function

The display will show "P2". The service function is now activated.

5.3 Adjusting the appliance



Always start the adjustment by P1 followed by P2.

5.3.1 Access to test points

- ▶ Remove the front of the appliance.




Fig. 11

[A] Air pressure test point

[B] Gas pressure test point

5.3.2 Adjusting the maximum flow (Parameter P1)

- ▶ Turn on the appliance using the ON/OFF button.
- ▶ Loosen the test point screw of the gas pressure test point [B].
- ▶ Connect the pressure gauge connection "+" to the gas pressure test point.
- ▶ Loosen the test point screw of the air pressure test point [A].
- ▶ Connect the negative (-) side of the pressure gauge to the air pressure test point [A].
- ▶ Enter the service mode by pressing and holding down the **P**, **+**, and **-** buttons simultaneously for 3 seconds.
- ▶ Display will show "P2".
- ▶ Press **-** until the display shows "P1".
- ▶ Press the button **P**.
- ▶ Display will show "E".
- ▶ Press **-** until the display shows "L1".
- ▶ Press the button **P**.
- ▶ The appliance is now ready for adjustment of the maximum gas flow.
- ▶ Open a hot water tap.
- ▶ Press **+** or **-** until the pressure gauge shows the value indicated in table 10.



If it is not possible to reach the differential pressure value:

- ▶ Adjust the pressure in the burner (section 5.3.4) and repeat the procedure for adjusting minimum flow.
- ▶ Press **P** for 3 seconds.
- ▶ The displayed value flashes as a sign of confirmation.
- ▶ Press **P**.
- ▶ Display will show "L1".
- ▶ Close the hot water tap.
- ▶ Press **+** until the display shows "E".
- ▶ Press the button **P**.
- ▶ Display will show P1.
- ▶ The adjustment of the maximum gas flow is completed.

5.3.3 Adjusting the minimum flow (Parameter P2)

- ▶ Press **+** until the display shows "P2".
- ▶ Press the button **P**.
- ▶ Display will show "E".
- ▶ Press **-** until the display shows "L2".
- ▶ Press the button **P**.
- ▶ Open a hot water tap.
- ▶ The appliance is now ready for adjustment of the minimum gas flow.

- ▶ Press **+** or **-** until the pressure gauge shows the value indicated in table 10.



If it is not possible to reach the differential pressure value:

- ▶ Adjust the pressure in the burner (section 5.3.4) and repeat the procedure for adjusting minimum flow.
- ▶ Press **P** for 3 seconds.
The displayed value flashes as a sign of confirmation.
- ▶ Press **P**.
Display will show "L2".
- ▶ Close the hot water tap.
- ▶ Press **+** until the display shows "E".
- ▶ Press the button **P**.
Display will show "P2".
- ▶ Simultaneously press the **P**, **+**, and **-** for 3 seconds.
Display will show the temperature selected.
- ▶ Disconnect the pressure gauge from the test points [A] and [B].
- ▶ Tighten the shutter screws of the test points [A] and [B].
The adjustment of the minimum gas flow is complete.

		Natural gas H	LPG
Ø injector	GWH16	1.7	1.25
	GWH20	10 x 2.0 5 x 1.7	10 x 1.5 5 x 1.3
	GWH26	2.0	1.55
Dynamic connection pressure (kPa)	GWH16	1.13	2.75
	GWH20		
	GWH26		
Burner pressure (kPa) - P0	GWH16	0.12	
	GWH20		
	GWH26		
Differential pressure of the burner MAX (kPa) - P1	GWH16	0.22 - 0.28	0.25 - 0.32
	GWH20	0.21 - 0.26	0.26 - 0.32
	GWH26	0.21 - 0.29	0.18 - 0.26
Differential pressure of the burner MIN (kPa) - P2	GWH16	0.03 - 0.06	0.04 - 0.06
	GWH20	0.03 - 0.05	0.05 - 0.07
	GWH26	0.02 - 0.05	0.03 - 0.06

Table 10 Pressure of the burner

5.3.4 Adjusting pressure at the burner (Parameter P0)



Burner pressure adjustment is only required if "L1" and "L2" cannot be achieved according to table. 10

- ▶ Enter the Service menu by pressing and holding down the **P**, **+**, and **-** buttons simultaneously for 3 seconds.
Display will show "P2".
- ▶ Press **-** until the display shows "P0".
- ▶ Press the button **P**.
- ▶ Open a hot water tap.
With the pressure gauge connected, let the value measured stabilise.
- ▶ Press **+** or until the pressure gauge shows the value indicated in table 10.
- ▶ Press **P** for 3 seconds.
The displayed value flashes as a sign of confirmation.
- ▶ Press **P** to exit this function.
Display will show P0.
- ▶ Close the hot water tap.
The adjustment of the burner pressure is complete.

5.4 Factory default settings

- ▶ Enter the Service menu by pressing and holding down the **P**, **+**, **-** and buttons simultaneously for 3 seconds.
Display will show "P2".
- ▶ Press **+** until the display shows "P4".
- ▶ Press the button **P**.
Display will show "E".
- ▶ Press **-** until the display shows "rP".
- ▶ Press the button **P**.
Display will show "P1".
- ▶ Press **P** for 3 seconds.
The displayed value flashes as a sign of confirmation.
- ▶ Press **P**.
Display will show "P1".
- ▶ Press **+** until the display shows "P2".
- ▶ Press the button **P** for 3 seconds.
The displayed value flashes as a sign of confirmation.
- ▶ Press **P**.
Factory default settings are now restored.

6 Maintenance (only by authorised service technician)

Bosch recommend that to maintain optimum performance from this appliance, servicing should be carried out by suitably licensed persons at intervals not greater than two (2) years.



Maintenance must only be performed by an authorised service technician.



DANGER:

Due to electric shock!

- ▶ Always isolate the electrical power to the appliance (by turning off the power point and removing the power plug from the electrical socket) before carrying out any work on electrical parts.
- ▶ Your appliance should only be attended to by a licensed service technician. To locate your nearest service provider, call:
AU 1300 30 70 37, NZ 0800 54 33 52
- ▶ Only use Bosch supplied replacement parts.

6.1 Periodic maintenance

Functional check

- ▶ Check the correct operation of all the safety, regulation and verification elements.

Heat exchanger

If the heat exchanger is showing signs of sooting:

- ▶ Remove the heat exchanger.
- ▶ Clean by applying a jet of water in the lengthwise direction of the fins.

NOTICE:

Damage to the appliance.

Damage to the heat exchanger.

- ▶ Do not apply a jet that is too strong or aimed in a direction other than that indicated.
- ▶ If the soot is not removed, use a stiff brush to carefully clean the fins.
- ▶ Regions with average/high water hardness: descale the inside of the heat exchanger and the connection pipes by using a diluted solution of hydrochloric acid or white vinegar.

- ▶ When reinstalling the heat exchanger replace the o-rings and seals.

Burner

- ▶ Inspect the burner and clean if necessary.

If cleaning is required:

- ▶ Dismantle the burner.
- ▶ Use a brush to clean the surface of the burner elements.
- ▶ Use a jet of air to blow the burner elements clean.

Water filter

- ▶ Close the cold water inlet isolation valve.
- ▶ Unscrew the water filter on the cold water pipe.
- ▶ Clean the water filter.

-or-

- ▶ Replace if required




Fig. 12 Water filter

6.2 Replacement of the fuse (electronic control unit)

- ▶ Open the electronic control unit.
- ▶ Remove the PCB from the electronic control unit.
- ▶ Replace the fuse located in the corner of the circuit board.




Fig. 13 Fuse replacement

6.3 Start-up after completion of maintenance

- ▶ Re-tighten all of the connections.
- ▶ Check the burner pressure.
- ▶ Check air tightness of the flue circuit with the front cover fitted.
- ▶ Check that there are no gas or water leaks.

7 Troubleshooting

Fitting, maintenance and repair must only be carried out by authorised technicians. The following table describes the possible solutions.

Display	Description	Possible solution
A0	Cold and hot temperature sensor damaged.	<ul style="list-style-type: none"> ▶ Check temperature sensor and associated connections. ▶ If the problem persists, call an authorised service technician.
A1	Temperature inside the water heater housing is high (heat exchanger calcified or sooted).	<p>The appliance automatically regulates its performance to avoid overheating.</p> <ul style="list-style-type: none"> ▶ If the problem persists, call an authorised service technician.
A4	Faulty air temperature sensor.	<ul style="list-style-type: none"> ▶ Call an authorised service technician.
A6	Faulty inlet water temperature sensor.	<ul style="list-style-type: none"> ▶ Check temperature sensor and associated connections. ▶ If the problem persists, call an authorised service technician.
A8	Faulty mixed water temperature sensor.	<ul style="list-style-type: none"> ▶ Check temperature sensor and associated connections. ▶ If the problem persists, call an authorised service technician.
A7	Faulty hot water outlet temperature sensor.	<ul style="list-style-type: none"> ▶ Check temperature sensor and associated connections. ▶ If the problem persists, call an authorised service technician.
A9	Hot water outlet temperature sensor is not fitted properly. Low incoming gas pressure.	<ul style="list-style-type: none"> ▶ Check temperature sensor and associated connections. ▶ If the problem persists, call an authorised service technician.
C7	Faulty fan.	<ul style="list-style-type: none"> ▶ Check if the fan is properly connected to ECU. ▶ If the problem persists, call an authorised service technician.
CA	Water flow above maximum specified value.	<ul style="list-style-type: none"> ▶ Check incoming water pressure. ▶ Install a pressure limiting valve if necessary.
CF	Blocked flue gas outlet.	<ul style="list-style-type: none"> ▶ Remove dirt or any other impediment in the flue and air inlet.
C1	Air flow insufficient for start-up.	<ul style="list-style-type: none"> ▶ Close and open a hot water tap. ▶ If the problem persists, call an authorised service technician.
E0	Failure of control module.	<ul style="list-style-type: none"> ▶ Unplug the electrical connection for 10 seconds. ▶ Reconnect and restart the appliance. ▶ If the problem persists, call an authorised service technician.
E1	Hot water temperature sensor detects overheating.	<ul style="list-style-type: none"> ▶ Let the appliance cool and try again. <p>If the problem persists, call an authorised service technician.</p>
E4	Air temperature sensor detects overheating (leaking combustion products inside the combustion chamber).	<ul style="list-style-type: none"> ▶ Switch off at the power point and remove the plug from the electrical socket. Do not try to Restart the appliance. ▶ Call a service agent immediately.
E9	Activated thermal fuse.	<ul style="list-style-type: none"> ▶ Call an authorised service technician.
EA	Flame not detected.	<ul style="list-style-type: none"> ▶ Check that the gas to the appliance has not been turned off. ▶ Unplug the electrical connection for 10 seconds. ▶ Reconnect and restart the appliance. ▶ If the problem persists, call an authorised service technician.
EC	Loss of ionization in less than 5 seconds during 5 times.	<ul style="list-style-type: none"> ▶ Unplug the electrical connection for 10 seconds. ▶ Reconnect and restart the appliance. ▶ If the problem persists, call an authorised service technician.





Display	Description	Possible solution
EE	Modulating solenoid valve disconnected.	<ul style="list-style-type: none"> ▶ Check solenoid connections. ▶ If the problem persists, call an authorised service technician.
EF	Wrong gas connected.	<ul style="list-style-type: none"> ▶ Call an authorised service technician.
F7	A flame is detected although the appliance is switched off.	<ul style="list-style-type: none"> ▶ Unplug the electrical connection for 10 seconds. ▶ Reconnect and restart the appliance. ▶ If the problem persists, call an authorised service technician.
F9	Safety solenoid valve disconnected.	<ul style="list-style-type: none"> ▶ Call an authorised service technician.
FA	Fault in the gas control valve.	<ul style="list-style-type: none"> ▶ Call an authorised service technician.
FC	Buttons stuck in a 'pressed' position for more than 30 seconds.	<ul style="list-style-type: none"> ▶ Release the button. ▶ If the problem persists, call an authorised service technician.
With indication,   but without existence of solar thermal system.	The temperature selected is lower than the minimum power that the appliance supplies.	<ul style="list-style-type: none"> ▶ Increase the hot water flow. -or- ▶ Select a higher temperature. If the problem persists: <ul style="list-style-type: none"> ▶ Call an authorised service technician.
With indication   and water temperature low.	High incoming water temperature or low flow rate can create this occurrence.	
	Appliance is making resonance noise (vibration).	

Table 11

Note: breakdowns diagnosed by the water heater through an indication in the LCD panel result in the blocking of the appliance for safety reasons. Once the problem is solved, you can reset the appliance by pressing the on/off button or by unplugging and replugging the power supply cord.

To locate your nearest service agent, call: AU 1300 30 70 37, NZ 0800 54 33 52.

8 Environment considerations

Environmental protection is a fundamental corporate strategy of the Bosch Group.

The quality of our products, their efficiency and environmental safety are all of equal importance to us and all environmental protection legislation and regulations are strictly observed. We use the best possible technology and materials for protecting the environment taking into account of economic considerations.

Packaging

We participate in the recycling programmes of the countries in which our products are sold to ensure optimum recycling.

All of our packaging materials are environmentally friendly and can be recycled.

Used appliances

Used appliances contain valuable materials that should be recycled.

The various assemblies can be easily dismantled and synthetic materials are marked accordingly. Assemblies can therefore be sorted by composition and passed on for recycling or disposal.

9 Water quality

All Bosch water heating appliances are constructed from high quality materials and components and all are certified for compliance with relevant parts of Australian and New Zealand gas, electrical and water standards.

Whilst Bosch water heaters are warranted against defects, the warranty is conditional upon correct installation and use, in accordance with detailed instructions provided with the heater. In the case of the water supplied to the heater, it is important that the water quality be of an acceptable standard.

The water quality limits/parameters listed in water quality table are considered acceptable and generally, Australian and New Zealand suburban water supplies fall within these limits/parameters.

In areas of Australia and New Zealand where water may be supplied, either fully or partly, from bores, artesian wells or

similar, one or more of the important limits may well be exceeded and the heater could, therefore, be at risk of failure.

Where uncertainty exists concerning water quality, intending appliance users should seek a water analysis from the water supplying authority and in cases where it is established that the water supply does not meet the quality requirements of the water quality table, the Bosch warranty would not apply.

Water quality table

Maximum levels

pH	Saturation Index (LSI) (Langelier)	Total Hardness	Chlorides	Sodium	Iron
6.5-9.0	+0.4 to -1.0 at 65 °C	200 mg/l	250 mg/l	180 mg/l	1 mg/l

Table 12

10 Warranty details

Robert Bosch (Australia) Pty Ltd

(Bosch) Manufacturer's Warranty

(Applicable for purchases from 1 January 2012)

All Bosch hot water units are carefully checked, tested and subject to stringent quality controls.

1. Warranty

Bosch offers, at its option, to repair or exchange this Bosch hot water unit or the relevant part listed in clause 2 below at no charge, if it becomes faulty or defective in manufacture or materials during the warranty period also stated in clause 2. This warranty is offered in addition to any other rights or remedies held by a consumer at law.

2. Warranty periods & coverage

- (a)** Domestic applications: 3 years (parts and labour)
- (b)** Heat exchangers used in domestic applications: 12 years (parts only)
- (c)** Commercial applications: 12 months (parts and labour)
- (d)** Heat exchangers used in commercial applications: 12 months (part and labour)

All warranty periods commence on the date of purchase of the hot water unit by the end-user. However, where the date of purchase by the end-user is more than 24 months after the date of manufacture, all warranty periods will automatically commence 24 months after the date of manufacture.

3. Warranty exclusions

This warranty is VOID if any damage to or failure of the hot water unit is caused wholly or partly by:

- (a)** faulty installation
- (b)** neglect, misuse, accidental or non-accidental damage, failure to follow instructions
- (c)** use of the unit for purposes other than which it was designed or approved
- (d)** unauthorised repairs or alterations to the unit without Bosch's consent
- (e)** use of unauthorised parts and accessories without Bosch's consent
- (f)** use of non-potable water or bore water in the hot water unit (see product instructions for further details)
- (g)** continued use after a fault becomes known or apparent.

This warranty DOES NOT include:

- (a)** costs of consumables or accessories
- (b)** wear and tear, normal or scheduled maintenance
- (c)** to the extent permitted by law, any damage to property, personal injury, direct or indirect loss, consequential losses or other expenses
- (d)** changes in the condition or operational qualities of the hot water unit due to incorrect storage or mounting or due to climatic, environmental or other influences.

NOTE: Any service call costs incurred by the owner or user of the hot water unit for any matter not covered by the terms of this warranty will not be reimbursed by Bosch, even if those costs are incurred during the warranty period. If the hot water unit is located outside the usual operating area of a Bosch service agent, the agent's travel, freight or similar costs are not covered by this warranty and must be paid by the owner or user of the hot water unit.

4. Warranty conditions

- (a)** Proof of purchase may be required.
- (b)** The hot water unit must be installed by an authorised and licensed installer.
- (c)** Proof may be required of the date of installation and correct commissioning of the hot water unit has been carried out to Bosch's satisfaction (such as a certificate of compliance).
- (d)** Repair or replacement of the hot water unit or any parts under this warranty does not lengthen or renew the warranty period.
- (e)** This warranty is not transferable and is only offered to the original purchaser of the hot water unit.
- (f)** No employee or agent of Bosch is authorised to amend the terms of this warranty.

(g) This warranty only applies to Bosch hot water units purchased from an authorised reseller and installed in Australia or New Zealand.

(h) To the extent that any condition or warranty implied by law is excludable, such condition or warranty is excluded.

5. How to lodge a warranty claim and warranty procedure

(a) Warranty claims must be made with the Bosch Customer Contact Centre (Australia: ph 1300 307 037; New Zealand: ph 0800 543 352). Please be ready to provide the model and serial numbers, date of installation, purchase details and a full description of the problem. Warranty claims must be made before the end of the warranty period.

(b) All warranty service calls must be conducted by an authorised Bosch service agent.

(c) Invoices for attendance and repair of a hot water unit by third parties not authorised by Bosch will not be accepted for payment by Bosch.

6. Privacy Act 1988 (Cth)

A customer's personal information collected during warranty claims may be used for the provision of customer support, for the provision of information about products and services and for other marketing activities undertaken by Bosch and its Bosch Service Agents who are authorised to carry out warranty repairs on behalf of Bosch (Purpose). Bosch is committed to protecting the privacy of its customers' personal information. It will act in compliance with the National Privacy Principles and HighFlow 6 720 817 545 (2016/02) Warranty details | 23 Privacy Act 1988 (Cth). Bosch will not forward customers' personal information to third parties other than for the Purpose. A customer can object at any time to the use of their personal information for the Purpose. Bosch will cease to use a customer's personal information accordingly if an objection is made.

7. Bosch contact details

If you have any questions about this warranty or to lodge a warranty claim, please contact:

Robert Bosch (Australia) Pty Ltd
1555 Centre Road, Clayton, Victoria 3168
Tel: Australia: 1300 307 037
Tel: New Zealand: 0800 543 352

IMPORTANT NOTE FOR AUSTRALIAN CONSUMERS

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods

fail to be of acceptable quality and the failure does not amount to a major failure.

Robert Bosch (Australia) Pty Ltd
Thermotechnology Division
1555 Centre Road
Clayton Victoria 3168

Australia
Phone: 1300 30 70 37
Fax: 1300 30 70 38
www.bosch-climate.com.au

New Zealand
Phone: 0800 54 33 52
Fax: 0800 54 33 55
www.bosch-climate.co.nz